


Installation position


Expansion options

#




KR

Stick switch, STD, installation position on the right	1-02071 standard
Stick switch, 3-position switch right (<i>additional charge: 59,00 €/switch</i>)	1-02033
Stick switch, 2-position switch right (<i>additional charge: 59,00 €/switch</i>)	1-02035




A

Switch 2POS-S-OX-AB, 2-position, short, - A	1-01978
Switch 2POS-L-OX-AB, 2-position, long, - A	1-01979
Switch 3POS-S-OXO-AB, 3-position, short, - A	1-01980
Switch 3POS-L-OXO-AB, 3-position, long, - A	1-01981 standard
Momentary switch 2POS-S-OM-AB, 2-position, short, - A	1-01982
Momentary switch 2POS-L-OM-AB, 2-position, long, - A	1-01983
Part momentary switch 3POS-L-OXM-AB, 3-position, long, - A	1-01984
Security switch 2POS-SL-A, 2-position, - A (<i>add. ch.: 29,90 €/switch</i>)	1-01985




B

Switch 2POS-S-OX-AB, 2-position, short, - B	1-01986
Switch 2POS-L-OX-AB, 2-position, long, - B	1-01987
Switch 3POS-S-OXO-AB, 3-position, short, - B	1-01988 standard
Switch 3POS-L-OXO-AB, 3-position, long, - B	1-01989
Momentary switch 2POS-S-OM-AB, 2-position, short, - B	1-01990
Momentary switch 2POS-L-OM-AB, 2-position, long, - B	1-01991
Part momentary switch 3POS-L-OXM-AB, 3-position, long, - B	1-01992
Security switch 2POS-SL-A, 2-position, - B (<i>add. ch.: 29,90 €/switch</i>)	1-01993




I

Slider Extension long, orange, position right - I (<i>add. ch.: 19,90 €/extension</i>)	1-02112
Slider Extension short, black, position right - I	1-02125 standard



C

Switch 2POS-S-OX-AB, 2-position, short, - C	1-01994
Switch 2POS-L-OX-AB, 2-position, long, - C	1-01995
Switch 3POS-S-OXO-AB, 3-position, short, - C	1-01996 standard
Switch 3POS-L-OXO-AB, 3-position, long, - C	1-01997
Momentary switch 2POS-S-OM-AB, 2-position, short, - C	1-01998
Momentary switch 2POS-L-OM-AB, 2-position, long, - C	1-01999
Part momentary switch 3POS-L-OXM-AB, 3-position, long, - C	1-02000



D

Switch 2POS-L-OX-AB, 2-position, long, - D	1-02001 standard
Switch 2POS-S-OX-AB, 2-position, short, - D	1-02002
Switch 3POS-L-OXO-AB, 3-position, long, - D	1-02003
Momentary switch 2POS-L-OM-AB, 2-position, long, - D	1-02004
Part momentary switch 3POS-L-OXM-AB, 3-position, long, - D	1-02390

Installation position

Expansion options

#

KL



Stick switch, STD, installation position on the left	1-02070 standard
Stick switch, 3-position switch left (<i>additional charge: 59,00 €/switch</i>)	1-02032
Stick switch, 2-position switch left (<i>additional charge: 59,00 €/switch</i>)	1-02034

E



Switch 2POS-S-OX-AB, 2-position, short, - E	1-02005
Switch 2POS-L-OX-AB, 2-position, long, - E	1-02006
Switch 3POS-S-OXO-AB, 3-position, short, - E	1-02007
Switch 3POS-L-OXO-AB, 3-position, long, - E	1-02008 standard
Momentary switch 2POS-S-OM-AB, 2-position, short, - E	1-02009
Momentary switch 2POS-L-OM-AB, 2-position, long, - E	1-02010
Part momentary switch 3POS-L-OXM-AB, 3-position, long, - E	1-02011
Security switch 2POS-SL-A, 2-position, - E (<i>add. ch.: 29,90 €/switch</i>)	1-02012

F




Switch 2POS-S-OX-AB, 2-position, short, - F	1-02013
Switch 2POS-L-OX-AB, 2-position, long, - F	1-02014
Switch 3POS-S-OXO-AB, 3-position, short, - F	1-02015 standard
Switch 3POS-L-OXO-AB, 3-position, long, - F	1-02016
Momentary switch 2POS-S-OM-AB, 2-position, short, - F	1-02017
Momentary switch 2POS-L-OM-AB, 2-position, long, - F	1-02018
Part momentary switch 3POS-L-OXM-AB, 3-position, long, - F	1-02019
Security switch 2POS-SL-A, 2-position, - F (<i>add. ch.: 29,90 €/switch</i>)	1-02020

J



Slider Extension long, orange, position left - J (<i>add. ch.: 19,90 €/extension</i>)	1-02111
Slider Extension short, black, position left - J	1-02124 standard

G



Switch 2POS-S-OX-AB, 2-position, short, - G	1-02021
Switch 2POS-L-OX-AB, 2-position, long, - G	1-02022
Switch 3POS-S-OXO-AB, 3-position, short, - G	1-02023 standard
Switch 3POS-L-OXO-AB, 3-position, long, - G	1-02024
Momentary switch 2POS-S-OM-AB, 2-position, short, - G	1-02025
Momentary switch 2POS-L-OM-AB, 2-position, long, - G	1-02026
Part momentary switch 3POS-L-OXM-AB, 3-position, long, - G	1-02027

H



Switch 2POS-L-OX-AB, 2-position, long, - H	1-02028 standard
Switch 2POS-S-OX-AB, 2-position, short, - H	1-02029
Switch 3POS-L-OXO-AB, 3-position, long, - H	1-02030
Momentary switch 2POS-L-OM-AB, 2-position, long, - H	1-02031
Part momentary switch 3POS-L-OXM-AB, 3-position, long, - H	1-02391